


INSTALLATION MANUAL



READ ME FIRST

Before you begin, read and understand this installation manual, take a moment and check all your Maxfort MF-TRG24 components and gather the assembly instructions for the various parts.

Please refer to the next page for a list of all the parts, quantities and tools required.


WARNING ! ⚠

Improper installation of this gear may void certain aspects of your warranty.


Maxfort will not be responsible for any damage caused by the failure to install the product according to these instructions.

Please call us if you have any questions about the installation of this product.

1. TOOLS NEEDED



Cordless
Driver




H4 & H5
Allen Wrench
Drill Bit

2. PARTS LIST

NO	PART NAME	QTY
1	SIDE MOUNT	1 set (R-L)
2	NARROW SLAT 1370 MM	3 pcs
3	WIND FAIRING	1 pcs
4	WIND FAIRING SUPPORT	1 pcs
5	L BUTTON HEAD BOLT M8 X 15	16 pcs
6	SPRING WASHER M8 X 13 X 2	4 pcs


NO	PART NAME	QTY
7	FLAT WASHER M8 X 18 X 1.5	4 pcs
8	T SLOT NUT M8	2 pcs
9	L BUTTON HEAD BOLT M6 X 15	12 pcs
10	NILON NUT	2 pcs
11	LED LIGHTBAR BRACKET	1 pair
12	LED LIGHTBAR	optional



3. INSTALLATION


3.1 SIDE MOUNT



The Side Mount (item 1) is already assembled, we have 2 different side of Side Mount that is Left and Right.



3.2 NARROW SLATS


Assemble eight Narrow Slats (item No 2) to Side Mount (item 1) using M8 x 15 bolt (item No 5). Tightening torque 8-10Nm / 5.9 ft lb - 7.38 ft lb. Take care when using a cordless driver.



TOOL USED	
	
Cordless Driver	H5 Allen Wrench Drill Bit


3.3 WIND FAIRING SUPPORT

Insert the T Slot Nut (item 8) and slide to its position that is at the middle. Attach the Wind Fairing Support using M8 x 15 bolt (item 5), M8 x 18 x 1.5 flat washers (item 7) and M8 x 18 x 1.5 spring washers (item 6).




3.4 WIND FAIRING

Center the Wind Fairing (item 3) and position the Wind Fairing Support (item 4) aligning the slotted holes. Secure the Wind Fairing to the bracket, using M6 x 15 Bolts (item 9). Fully tighten the wind fairing to the brackets.



3.5 ROOF RACK INSTALLATION

Center the roof rack and position the roof rack aligning the slotted holes. Secure the roof rack to the roof, using M8 Bolts. Fully tighten the roof rack to the roof.



4. NOTES

This image shows a full page of white paper with horizontal dashed lines, typical of primary-ruled notebook paper. The lines are evenly spaced and run across the width of the page. There are no margins, text, or other markings on the paper.